

NEPTUNE Pro Gaming Keyboard

Software User Guide




Page 3	Main Interface			
		Main Interface	04	1
Page 5	Lighting Effects			
		Lighting Effect Interface	0	6
		●Static, Pulse	0	7
		Wave	O:	8
		Spiral Rainbow, Sine Wave	O	ç
		Snake Marquee, Aura	1	C
		●Star, Rain	1	1
		Off, Customize	1	2
Page 13	Key Customize			
		Key Customize	14	4
		Reset, Keyboard Key	15	5
		Mouse Key, Mouse Wheel	16	õ
		Mouse Rapid Fire	17	7
		Multimedia, System	18	3
		Macro	19	Э
Page 20	Macro Interface/Setting			
		Macro Setting	21	1
Page 22	Setting			
		Setting Description	23	3



| Content 1 | Main Interface









Content 2

Lighting Effects

Lighting Effects:

Static/Pulse/

Wave/Spiral


Rainbow/Sine Wave/Snake

Marquee/Flow/S

tars/Rain/Off/Cu

stomize





Effect)

Keyboard (Lighting

Lighting Effect Direction

- **Lighting Brightness**
- 2. **Lighting Speed**







Static:

Brightness Selection



Pulse:

- 1. Brightness Selection
- 2. Speed Selection





Wave:

- 1. Brightness Selection
- 2. Speed Selection
- 3. Direction: Left/Right





Spiral Rainbow:

- 1. Brightness Selection
- 2. Speed Selection
- 3. Direction: Inward/Outward



Sine Wave:

- 1. Brightness Selection
- 2. Speed Selection





Snake Marquee:

- 1. Brightness Selection
- 2. Speed Selection
- 3. Direction: Down/Up



Aura:

- 1. Brightness Selection
- 2. Speed Selection



Stars:

- 1. Brightness Selection
- 2. Speed Selection



Rain:

- 1. Brightness Selection
- 2. Speed Selection







Turn Off Lighting Effect



Customize:

- 1. Group (5 Default Customize Gaming Effect): FPS1/FPS2/MMO/MOBA/RTS
- 2. Operate:

On: Change all keys to selected color

Off: Turn off all key lighting

Light: Turn on single key lighting

No Light: Turn off single key lighting





Content 3

Key Customize



Game Mode Key:

Turn on Game Mode via clicking Game Mode Key on keyboard

Fn Key:

Cannot setup Fn Key

Customize List:

- 1. Click to open list:
- Reset/Keyboard Key/Mouse Key/ Mouse Wheel/Rapid Fire/ Multimedia/System/Macro
- 3. Please Note:

Game Mode must be turned on to activate customized key function.









Reset:

- 1. Reset selected key setting to default
- 2. Click Apply to confirm



Keyboard Key:

- 1. First click on the desired key to setup
- 2. Please Enter Key: Above example shows the original S key is now C key.
 - (Yellow Highlight indicates customized key)
- 3. Click Apply to confirm





Mouse Key, Mouse Wheel

Mouse Key:

- 1. Click to open: (Left Click/Middle Click/Right Click/Forward/Backward)
- 2. Click Apply to confirm



Mouse Wheel:

- 1. Mouse Wheel: Select Scroll Up/Down
- 2. Scroll: Enter scroll value, maximum 127
- 3. Click Apply to confirm



Rapid Fire:

- 1. Enter value between each click (Maximum 255)
- 2. Enter number of click (Maximum 255 clicks)
- 3. Click Apply to confirm







Multimedia:

- 1. Media Player/Play/Pause/Previous Track/Next Track/ Volume Down/Volume Up/Mute/Website/Refresh/Stop/ Previous Page/Next Page/Bookmarks/Search/My Computer/Calculator/Mails
- 2. Click Apply to confirm



System:

- 1. Power
- Sleep
- Wake
- 4. Click Apply to confirm





Macro:

- 1. Select Macro
- 2. Select Macro Finish: Standard/Release/Click/ Stop after release/Cycle (Enter cycle value below)
- 3. Click Apply to confirm



Macro Cycle:


1. Number of Macro cycle (Maximum of 255 cycles)





Content 4 Macro Interface/Setting

3.



Delay: Delay time between each action

- **Change Macro**
- Mouse Action (Click to open action list, click again to close mouse action
- **Start Recording:** Click to start Macro recording, click Stop Recording to stop

- Top: Move to top
- Bottom: Move to bottom
- Delete Macro action
- Clear all Macro action
- Save: Save Macro
- Cancel: Cancel Macro

Action: Keyboard/Mouse action

Delay: Action delay



Content 5 Setting



